snow peak
outdoor lifestyle creator since1958

ST-210
アルマストーブ
［薪ストーブ指定製品・幕体一覧］

取扱説明書 : Ver 1.00 : 2026.11

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。
本資料では、ST-210 アルマストーブと組み合わせて使用する製品・幕体、および幕体内での設置方法をご案内します。
●本製品は、当社がST-210 アルマストーブとの組み合わせを定めた製品（以下「指定製品」といいます。）に、定められた組み合わせで組み込んで使用してください。本製品だけを地面などに直接置いて使用しないでください。
●本製品を幕体内で使用する場合は、当社がST-210 アルマストーブとの組み合わせを定めた幕体（以下「指定幕体」といいます。）と組み合わせて使用してください。
●使用前に、本資料および本製品・指定製品・指定幕体に付属の取扱説明書を必ず確認してください。

最新版はこちらからご確認ください。
https://www.snowpeak.co.jp/pdf/products/ST-210/ST-210_compatibility.pdf

※本資料の内容は、表題部に記載のバージョンおよび発行年月時点の情報です。製品の追加・仕様変更等により内容が更新される場合があります。印刷または端末へ保存して保管する場合も、使用前に当社Webサイトで最新版をご確認ください。
※キャンプ場など通信環境が不安定な場所で使用する場合は、事前に通信可能な環境で最新版をご確認の上、必要に応じて印刷または端末へ保存してください。
※インターネットを利用できない場合や、Webサイトでの確認が難しい場合は、使用前に弊社ユーザーサービスへお問い合わせください。

警告 **●本資料に記載された製品・幕体の組み合わせ以外では絶対に使用しないでください。記載されていない組み合わせで使用すると、一酸化炭素中毒や火災などの重大な事故につながるおそれがあります。**

指定製品・指定幕体一覧

ST-210 アルマストーブは、下記に記載された指定製品・指定幕体との組み合わせで使用してください。
使用前に、使用する製品および幕体に付属の取扱説明書も必ず確認してください。

■指定幕体一覧

ST-210 アルマストーブが使用可能な幕体		必ず組み合わせて使用する製品	
TP-672	ランドロック X	TP-672-2	ランドロック X フライカバーTC
TP-940	メラク Pro.	TP-940TCF	メラク Pro. フライカバーTC

■指定製品一覧

LV-200	アルマスタンド
CK-149	アイアングリルテーブル フレーム
CK-150	アイアングリルテーブル フレームロング
CK-903/913	セパレートIGTフレーム 3ユニット
CK-904/914	セパレートIGTフレーム 4ユニット
GF-015	ガーデンユニットテーブル ウッドトップセット ※幕体内では使用できません。

■ 指定マルチファンクションテーブルー覧

注意 ●竹天板製品はストーブの熱により、反り・割れ・変色が起きるおそれがあります。注意してご使用ください

CK-116TR	マルチファンクションテーブル竹
CK-117TR	マルチファンクションテーブルロング竹
CK-116TL	マルチファンクションテーブル Light Bamboo
CK-117TL	マルチファンクションテーブルロング Light Bamboo

■ 指定トレーー覧

CK-026	リッドトレー ハーフユニット
CK-085	ステンレストレー 1ユニット
CK-125TR	ウッドテーブルS竹
CK-126TR	ウッドテーブルW竹

■ 指定IGT脚一覧

※幕体内では、660脚および 830脚を絶対に使用しないでください。
本製品と幕体の天井との距離が近くなり、熱により幕体を損傷するおそれがあります。

品番	品名	幕体内	幕体外（単品使用）
CK-109	300脚セット	○	○
CK-112	400脚セット	○	○
CK-113	660脚セット	×	○
CK-114	830脚セット	×	○

指定幕体への設置方法


現在の指定幕体への設置方法は、ST-210 アルマストーブに付属の取扱説明書に記載の方法から変更ありません。
取扱説明書に従って設置してください。
指定幕体の追加等により、取扱説明書に記載のない設置方法が必要となる場合は、本資料に掲載します。

指定幕体への煙突の固定方法

TP-672 ランドロック Xの場合

［薪ストーブ設置のために開放する出入口パネル］
煙突および薪ストーブを設置するため、**薪ストーブを設置する側の**シェルターおよびフライカバーTCの出入口パネルを開放した状態で、煙突を設置してください。


［煙突と幕体との固定］
シェルターの図の位置に自在付ロープ（3.7m）のカラビナを取り付け、適度にテンションをかけてください（4箇所）。このときにロープとカラビナの固定箇所がずれている場合は煙突を回転させて位置を調整してください。また、ロープが直に煙突に触れていないこと、カラビナがずれていないか確認してください。




TP-940 メラク Pro.の場合

［薪ストーブ設置のために開放する出入口パネル］
煙突および薪ストーブを設置するため、シェルターおよびフライカバーTCの**出入口パネルを両側とも開放してください。**

※煙突を差し込む際は、両側の出入口パネルを開き、煙突穴と反対側の出入口から入れてください。



［煙突と幕体との固定］
シェルターの図の位置に自在付ロープ（3.7m）のカラビナを取り付け、適度にテンションをかけてください（4箇所）。このときにロープとカラビナの固定箇所がずれている場合は煙突を回転させて位置を調整してください。また、ロープが直に煙突に触れていないこと、カラビナがずれていないか確認してください。



不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。
スノーピークユーザーサービス
0120-010-660（9:00～17:00）
Email:userservice@snowpeak.co.jp

株式会社スノーピーク
〒955-0147 新潟県三条市中野原456
Tel.0256-46-5858 / Fax.0256-46-5860
www.snowpeak.co.jp

Instruction Manual : Ver 1.00 : 2026.11

ST-210

Alma Stove
[List of Designated Wood Stove Products and Shelters]

Thank you for purchasing a Snow Peak product.
This document provides information on the products and shelters that can be used with the ST-210 Alma Stove, as well as installation methods inside designated shelters.

- This product must be installed in and used as part of a product for which Snow Peak has specified a combination with the ST-210 Alma Stove (hereinafter referred to as a "designated product"), in the specified combination. Do not use this product on its own by placing it directly on the ground or other surfaces.
- When using this product inside a shelter, use it only with a shelter designated by Snow Peak for use with the ST-210 Alma Stove (hereinafter referred to as a "designated shelter").
- Before use, be sure to read this document and the Instruction Manuals included with this product, the designated product, and the designated shelter.

Check here for the latest information.
https://www.snowpeak.co.jp/pdf/products/ST-210/ST-210_compatibility.pdf

*** The information in this document is current as of the version and issue date shown above. The information may be updated due to product additions, specification changes, or other reasons. Even if you have printed or saved this document to your device, always check the Snow Peak website for the latest version before use.**

*** When using the wood stove at a campsite or other location where the network connection is unstable, check the latest version beforehand in an environment where a connection is available, and print it out or save it to your device if necessary.**

*** If it is not possible to access the Internet or it is difficult to check the website, please contact Snow Peak Customer Service before use.**

WARNING • Do not use this product with any products, shelters, or combinations other than those specified in this document. Doing so may result in serious accidents, such as carbon monoxide poisoning or fire.

Designated Products and Designated Shelters

Use the ST-210 Alma Stove only with the designated products and shelters listed below, in the specified combinations.
Before use, be sure to read the Instruction Manuals included with the products and shelters you are using.

■ List of designated shelters

Designated shelter		Product to be used in combination	
TP-672	Landlock X	**TP-672-2**	Landlock X Fly Cover TC
TP-940	Merak Pro.	**TP-940TCF**	Merak Pro. Fly Cover TC

■ List of designated products

LV-200	Alma Stand
CK-149	IGT 3 Unit Frame
CK-150	IGT 4 Unit Frame
CK-903/913	Collapsible IGT Three Unit Frame
CK-904/914	Collapsible IGT Four Unit Frame
GF-015	Garden Unit Table * This product cannot be used inside the shelter.

■ List of designated multi-function tables

CAUTION • Bamboo tops on products may warp, split, or become discolored if exposed to heat from the stove. Please be careful when using such products.

CK-116TR	Bamboo Table Extension, Small
CK-117TR	Bamboo Table Extension, Large
CK-116TL	Regular IGT Extension Light Bamboo
CK-117TL	Long IGT Extension Light Bamboo

■ List of designated trays

CK-026	Lid Tray Half Unit
CK-085	Stainless Single Unit Tray
CK-125TR	IGT Bamboo Insert Short
CK-126TR	IGT Bamboo Insert Wide

■ List of designated IGT legs

* Never use the IGT Sitting Height 660mm Leg or IGT Sitting Height 830mm Leg inside the shelter. Using either leg inside the shelter reduces the clearance between this product and the shelter ceiling, potentially causing heat damage to the shelter.

Product code	Product name	Inside the shelter	Outside the shelter (single item use)
CK-109	IGT Ground Height 300mm Leg Set	○	○
CK-112	IGT Ground Height 400mm Leg Set	○	○
CK-113	IGT Sitting Height 660mm Leg Set	×	○
CK-114	IGT Sitting Height 830mm Leg Set	×	○

Installation Methods for Designated Shelters


The installation methods for the currently designated shelters remain unchanged from those described in the Instruction Manual included with the ST-210 Alma Stove.
Install the product according to the Instruction Manual.
If additional designated shelters or other changes require installation methods not described in the Instruction Manual, they will be provided in this document.

How to Secure the Chimney to Designated Shelters

For TP-672 Landlock X

[Doorway Panels to Open When Installing the Wood Stove]
To install the chimney and wood stove, fully open the doorway panels of both the shelter and Fly Cover TC **on the side where the wood stove will be installed** before installing the chimney.

[Securing the Chimney to the Shelter]
Attach the carabiners of the ropes with tensioners (3.7m / 12.1') to the positions shown in the shelter illustration and apply an appropriate amount of tension (4 locations). If the rope and carabiner attachment points are misaligned, rotate the chimney to adjust their positions. Also, check that the rope is not in direct contact with the chimney and that the carabiners are not misaligned.




For TP-940 Merak Pro.

[Doorway Panels to Open When Installing the Wood Stove]
To install the chimney and wood stove, **fully open the doorway panels on both sides** of the shelter and Fly Cover TC.

* When inserting the chimney, open the doorway panels on both sides and bring the chimney in through the doorway on the opposite side from the chimney hole.

[Securing the Chimney to the Shelter]
Attach the carabiners of the ropes with tensioners (3.7m / 12.1') to the positions shown in the shelter illustration and apply an appropriate amount of tension (4 locations). If the rope and carabiner attachment points are misaligned, rotate the chimney to adjust their positions. Also, check that the rope is not in direct contact with the chimney and that the carabiners are not misaligned.



Snow Peak USA, Inc.
404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc.
456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan
Tel. +81 256-46-5858 / Fax. +81 256-46-5860
www.snowpeak.co.jp